

A (BRIEF) GUIDE
TO USING YOUR
DELUXE MILK FROTHER

KuissentialTM

Get Started


Before we get started, let's clear something up...

Is it **Cuissential** or **Kuissential**??

While purchasing this item, you may have noticed some reviews on our page, or some other mentions of **Cuissential** and wondered what that is all about.

Is **Cuissential** the same as **Kuissential**?

We just want to let you now that yes, **Kuissential** and **Cuissential** are the same brand, same people, same customer service, and same products.

We just recently started transitioning the name to **Kuissential** with a **K**. That said, everything else about the brand is staying exactly the same. If you own any **Cuissential** products from before, you can still get the same great customer service and support. Also, we will continue to honor ALL **Cuissential** product warranties or issues.

Sorry if there was any confusion!

We hope you love your New **Kuissential** Milk Frother!

All the best,
Team **Kuissential**

Thank You! Thank You! Thank You!

Just thanking you for purchasing our *Deluxe Milk Frother*! We are a young company and your business means a lot to us!

It's really important to us to start **Kuissential** on the right foot and make sure that you are happy with your *Deluxe Milk Frother*. We know if you love it, you'll stick around as we grow. That's the type of relationship we want to build, something that lasts.

If you could help by leaving an honest review of your *Deluxe Milk Frother* on the product page, that would be tremendous. You'd also be helping others by letting them know if the *Deluxe Milk Frother* is a winner or not. Thanks for taking the time to read this!

For helpful articles and any questions please visit **Kuissential.com**

We hope you love your *Deluxe Milk Frother*!

All the best,
Team **Kuissential**


Returns and Defects:

If you happen to receive a defective frother, please e-mail team@Kuissential.com and we will take care of you ASAP. The odds are very low, but sometimes defects happen. We promise to make sure you are happy with your purchase.



Before Your First Use


Before your first use, we recommend that you clean the appliance thoroughly. Please refer to the section "Cleaning your Deluxe Frother".

Parts Diagram




Using Your Deluxe Frother


Whisks	Functions	Max Capacity	Completion Time
	Frothed Milk - Cold	115ml	65s
	Frothed Milk - Heated	115ml	80-90s
	Heated Milk (With a small amount of froth)	250ml	130-140s



Step 1



Step 2



Step 3

STEP 1 - Select the appropriate whisk based on the diagram above.

STEP 2 - Pour milk into the jug up to the "max" line based on the type of whisk you are using. (See the diagram above)

STEP 3a - For **HOT Milk / Froth** - **PUSH** the button to start. The BLUE and RED lights will turn on while the frother is in use. After the frother finishes, the RED light will flash for 30 seconds and the frother will turn off.

STEP 3b - For **COLD Milk / Froth** - **HOLD** the button for **2-3 seconds** until **ONLY** the BLUE light turns on. The BLUE light will stay on while the frother is in use. After about 65 seconds the frother will finish and the RED light will flash for 30 seconds.

STEP 4 - Enjoy delicious, barrista-quality frothed milk right in your own home!

Recommended Servings

Frothed Milk

Cappuccino - 1/3 espresso, Add 2/3 frothed milk. Top with cocoa powder.

Latte Macchiato - Pour frothed milk in a tall glass. Add espresso carefully along rim of the glass.

Instant frothy coffee - Make instant coffee. Add frothed milk.

Hot Milk

Cafe Latte - 1/3 espresso shot. Add 2/3 heated milk and stir.

Hot Chocolate - Pour heated milk in to a large mug. Add chocolate powder and stir to mix.

Instant Coffee with Milk - Place instant coffee granules in a cup Add hot milk and stir to mix.

Cleaning your Deluxe Frother

- We recommend cleaning your frother immediately after each use.
 - Always clean your frother with the power plug removed from the wall.
 - Remove the jug from the power base before cleaning. Separate the lid and the silicon ring from the jug. Never immerse the jug or the base in water.
 - THE JUG: Clean immediately after each use. Flush and clean the inner walls using warm soapy water and a non-abrasive cloth or sponge. Wipe dry with a soft cloth.
 - THE LID: Separate the lid and the silicon ring from the jug. Rinse directly with water.
 - THE BODY: Clean the body with a soft cloth or sponge. Never use sharp cleaning agents, hard nylon brushes or metal brushes to avoid scratches on the stainless steel surface! Never clean with metal objects and never use abrasives.
 - THE WHISKS: Remove from the jug and wash with warm water. Dry and store in a safe place. Do not them in the dishwasher.
-

Warning

- Do not immerse your frother in water or other liquids. This would put the frother in danger of short-circuiting!
- Never operate a damaged frother. This includes damaged cables.
- Do not place the appliance on a polished wood surface. This may damage the wood.
- Only operate the frother through a professionally installed socket supplying the correct voltage.
- Do not use this frother with extension cables.
- Never let the main cable hang loose. Do not remove the plug with wet hands. Do not lay or hang the cable on hot surfaces or let it come into contact with oils.
- Unplug the frother: after each use, when the appliance is not in use, before changing accessories, and while cleaning the appliance.
- Do not touch the metal parts or the housing when the frother is in use. This may cause burns or scalding.
- Do not operate this frother with a damaged cord or plug. If the supply cord is damaged, contact team@cuissential.com for help.
- This appliance conforms to directive 89/336 CEE regarding electromagnetic compatibility.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should not play with the milk frother. This is not a toy!
- Do not operate the frother outdoors.
- Do not operate without milk in the jug.
- Always attend the frother while in use.
- Turn the appliance and main power off when not in use.
- Never touch rotating parts. This may cause injury!
- Do not exceed the filling capacity or the frother may overflow!
- The frother is to be used only with the base unit provided.
- Never operate the frother on uneven surfaces.
- This frother is not designed for commercial or industrial use; it is for household use only.
- Do not insert any objects and/or fingers in the appliance apertures.
- 120V 60 Hz, 500 W This appliance is tested according to UL regulations and corresponds to the UL directives.

Tips

- Use whole milk (fat content >3.0%) for best results.
 - Store the whisks in a safe place. They are small and can easily be lost.
 - After frothing or heating allow 2 minutes for the thermostat to reset before using again. To shorten this time, rinse with water and wipe dry after each use.
 - The frother is designed to heat and froth milk. If you add flavorings such as coffee granules or chocolate powder, ensure it is cleaned immediately and thoroughly after use.
-

Troubleshooting

- If the frother stops working during operation, the jug temperature may be too high. To solve this problem, rinse the inside of the frother with cold water to reduce the temperature and try again. If this doesn't solve the problem, email team@Kuissential.com for more help.
 - If the motor stops working, it is possible that it wasn't cleaned properly and the motor locked. To solve this, clean the shaft sleeve and move it by hand to loosen it.
 - If this doesn't work, email team@Kuissential.com
-

Any questions?

If you have any questions please feel free to visit [Kuissential.com](https://www.kuissential.com) or shoot a message to team@Kuissential.com

Enjoy!