

A (BRIEF) GUIDE  
TO USING YOUR  
JUICE EXTRACTOR

**Kuissential™**

Get Started →

Thank You! Thank You! Thank You!

Just thanking you for purchasing our *Two-Speed Juice Extractor*! We are a young company and your business means a lot to us!

It's really important to us to start **Kuissential** on the right foot and make sure that you are happy with your *Two-Speed Juice Extractor*. We know if you love it, you'll stick around as we grow. That's the type of relationship we want to build, something that lasts.

If you could help by leaving an honest review of your *Two-Speed Juice Extractor* on the product page, that would be tremendous. You'd also be helping others by letting them know if the *Two-Speed Juice Extractor* is a winner or not. Thanks for taking the time to read this!

For helpful articles and any questions please visit **Kuissential**.com

We hope you love your *Two-Speed Juice Extractor*!

All the **Kuissential**  
Team

# IMPORTANT SAFEGUARDS

CAREFULLY READ ALL INSTRUCTIONS THOROUGHLY BEFORE OPERATING. WHEN USING ELECTRICAL APPLIANCES, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

- To protect against fire, electrical shock and injury to persons, do not immerse the appliance, motor base, cord or plug in water or any other liquid.
- Close supervision is necessary when the appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning or attempting to move the appliance.
- Avoid contact with moving parts
- Regularly inspect the supply cord, plug and actual appliance for any damage. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner. Contact Kuissential customer support for assistance.
- The use of attachments not recommended or sold by Kuissential may cause fire, electric shock or injury.
- This appliance is for household use only. Do not use this appliance for anything other than its intended use. Do not use in moving vehicles or boats. Do not use outdoors. Misuse may cause injury.
- Do not let the power cord hang over the edge of a table or counter top.
- Do not let the power cord touch hot surfaces, including stove, or become knotted.
- Always make sure the lid is clamped securely in place (with safety locking arm) before the motor is turned on. Do not unfasten the clamps (safety locking arm) while the juicer is in operation.
- Always ensure the juicer is turned off after each use. Make sure the juicing disc has stopped rotating and the motor has completely stopped before disassembling.
- Do not push food into the feed tube with your fingers or other utensils. Always use plunger. Do not place hand or fingers into the feed tube

when it is attached to the appliance. If food becomes lodged in feed tube, use plunger provided or another piece of fruit or vegetable to push it down. Turn motor off and ensure that all moving parts have stopped before disassembling juicer to remove the remaining food.

- Do not use appliance if the juicing disc is damaged.
- Do not modify the plug in any way. If the unit has a 2-pin plug it is a polarized plug. To reduce the risk of electric shock, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician.

## Additional Safeguards

- Remove and safely discard any packaging material or promotional labels before using the juicer for the first time.
- To eliminate choking hazard for young children, remove and safely discard the protective cover fitted to the power plug of this appliance.
- Do not touch the small cutting blades/teeth in the base of the juicing disc.
- Always make sure the juicer is properly and completely assembled before connecting to power outlet and operating.
- Ensure that the surface where the appliance operates is stable, level, clean and dry.
- Vibration can occur during normal operation.
- Any significant spillage onto the surface under or around the appliance, or onto the appliance itself, should be cleaned and dried before continuing to use the appliance.
- When using this appliance, provide adequate air space above and on all sides for circulation.
- This juicer is only designed to juice fruits and

vegetables. Do not use any frozen fruits or vegetables.

- Hard fruits and vegetables will put excess strain onto the motor if a low speed is selected.
- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not leave the appliance unattended when in use.
- Keep hands, fingers, hair, clothing as well as spatulas and other utensils away from appliance during operation.
- Keep the appliance clean. Refer to care and cleaning section.
- Any maintenance other than cleaning should be performed by an authorized Kuissential Service Center. Do not attempt to repair or service juicer. Contact Kuissential Customer Support for assistance.
- If any of the contained instructions or warnings are not understood please contact Kuissential Customer Support for assistance.

## Short cord instructions

Your Kuissential appliance is fitted with a short power supply cord to reduce personal injury or property damage resulting from pulling, tripping or becoming entangled with a longer cord. If an extension cord is used, 1) the marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance, 2) the cord should be arranged so that it will not drape over the countertop or table-top where it can be pulled on by children or tripper over unintentionally and 3) the extension cord must include a 3-prong grounding plug.

## Returns and defects

If you happen to receive a defective juicer, please e-mail [Team@Kuissential.com](mailto:Team@Kuissential.com) and we will take care of you ASAP. The odds are very low, but sometimes defects happen. We promise to make sure you are happy with your purchase. You can also email us if you need any replacement parts.



# PARTS DIAGRAM



- |                |                 |                   |                              |
|----------------|-----------------|-------------------|------------------------------|
| 1. Plunger     | 5. Spout        | 9. Feed Tube      | 12. Juice Jar (not pictured) |
| 2. Pulp Bucket | 6. Base         | 10. Lid           |                              |
| 3. Body        | 7. Juicing Disc | 11. On/Off switch |                              |
| 4. Locking Arm | 8. Power cord   |                   |                              |

## PRIOR TO FIRST USE

Before using your juicer for the first time, or after prolonged storage without use, wash any parts that will come into contact with food.

## USING YOUR JUICER

### Assembly before use

- Place the body (3) on a flat surface, e.g. a kitchen counter, and make sure it is standing firmly on the four suckers underneath.
- Place the base (6) on the body so that the spout (5) fits in the slot on the side of the body.

- Push the pulp bucket (2) up under the drain edge on the base so that it locks on the foot of the body tightly.
- Carefully lock the juicing disc (7) onto the base.
- Be careful not to touch the sharp parts inside the juicing disc.
- Make sure that the juicing disc sits properly on its base, so that the gear on the bottom of the disc engages the gear in the base.
- Make sure that the juicing disc doesn't sit too loosely on the base and that it rotates evenly.
- Place the lid (10) on the appliance so that it covers both the fruit pulp bucket and the juicing disc. Make sure that the lid fits tightly onto the base.
- Turn the locking arm (4) to the vertical position and make sure that it engages the lid and locks it completely. The lock mechanism makes a clicking sound when this is done correctly.
- Place the juice jar under the spout.
- The juicer is now ready to use.

## Preparing fruits and vegetables for juicing

- Always wash fruits and vegetables thoroughly before juicing.
- It is not necessary to remove seeds, pits or thin peels before using the juicer.
- Fruits with thick peels such as oranges and lemons must be peeled before juicing. Some recipes call to remove all the peel (including the pith), as even small amounts of peel can impart an unpleasant taste to the juice.
- It is also necessary to remove large pits (such as plum and apricot pits) to avoid damaging the juicer.
- Large fruits and vegetables should be cut into pieces that can fit into the feed tube (9).

## Use

- Start the appliance by turning the =On/Off switch to position "1" (low speed) or position "2" (high speed).
- The low speed setting is good for juicing soft fruits and vegetables.
- The high speed setting is good for juicing harder fruits and vegetables.
- Feed the selected fruits and/or vegetables into the juicer through the feed tube a little at a time, pushing them down using the plunger (1).

- Make sure that you turn the plunger so that the groove in the feed tube fits into the plunger properly.
- Long vegetables such as carrots should be fed into the feed tube thin end first.
- Press the fruits and/or vegetables gently with the plunger. Too much pressure reduces the amount of juice extracted and can damage the juicer.
- Stop the appliance before removing the plunger to add more fruit/vegetables in order to avoid to avoid splashes.
- Keep an eye on the pulp bucket and stop juicing before it becomes too full.
- Always turn off the power by turning the "On/Off" button to OFF position before taking off the lid.

Please note: Do not leave the juicer running for more than 3 minutes at a time. If the appliance has been running for 3 minutes, allow it to cool down for 20 minutes before you use it again.

## Tips

- If you line the fruit pulp holder with a plastic bag before juicing, it will be easier to clean the appliance.
- Use fresh fruits and vegetables - they contain the most juice.
- Good candidates for juicing include pineapple, apples, cucumbers, celery, carrots, spinach, melons, tomatoes and most citrus fruits.
- The various varieties of apple yield juice with different flavors and consistency. Experiment with different combinations to find your own favorite.
- Leafy green vegetables such as cabbage and spinach can be juiced. Roll the leaves into cylinders of an appropriate size before feeding them into the funnel. This helps extract the most juice possible.
- Fibrous fruits and vegetables as well as those with very firm flesh such as bananas, mangoes, papayas and avocados are not well-suited to juicing, as the result is often mashed fruit instead of juice.
- All types of juice should be consumed right after juicing, as fresh juice quickly loses important nutrients when exposed to the oxygen in the air. Taste can also be affected.
- Pure apple juice turns brown quickly when exposed to air. To prevent discoloration, serve apple juice immediately after juicing or add a little lemon juice.
- Remember that fruit pulp can be used in cakes, vegetable lasagna, muffins, etc.

## Storage

- Ensure the appliance is clean and dry before storing.
- The appliance contains sharp parts - keep out of the reach of children.

## Cleaning

- Remove the plug from the wall socket and allow the apparatus to cool down before cleaning.
- The best way to clean the body is with a slightly dampened cloth and, if necessary, a little detergent. Do NOT immerse the body in any form of liquid!
- The juicing disc, pulp bucket, base and all other detachable parts can be washed by hand or in a dishwasher. Use the included brush to clean the juicing disc thoroughly and make sure the fine holes in the disc are unblocked. If the holes are too difficult to unblock using the brush, you can loosen them by using hot water with 10% lemon juice. Soak the juicing disc in warm water immediately after use to prevent the juice from drying and clogging the holes.
- Be careful not to touch the sharp parts in the bottom of the juicing disc.
- Do not use any kind of strong or abrasive cleaning agent on the juicer or its accessories. Never use a scouring sponge or similar to clean it, as the surface may be damaged.
- Allow all parts of the juicer to dry completely before reassembling it after cleaning.

For usage tips, guides  
and more:

**Kuissential.com**